

THE LOCKHEED F-117A NIGHTHAWK

The Lockheed F-117A Nighthawk is the result of a long and very secret development program dating back to the early 1970's. Numerous attempts and tests were conducted to see if an aircraft could be designed to hide from radar observation. The Lockheed U-2 was painted with a kind of painr which can absorb the ware of radar. the Lockheed SR-71 also had the paint which can be against the shape of radar and absorb the ware of radar. The production F-117A made its first flight on October 15 1982 from the remote fight test facility at Groom Lake. Nevada. The aircraft is a special mission fighter bomber fully capable of performing in total darkness. The F-117A is capable of being flown worldwide and has inflight aerial refueling. Flight cruise altitudes are normally near 7600m. The F-117 Nighthawk is flown by pilots of the 37th Tactical Fighter wing of the USA TACTICAL Air Command from the Tonopah Test Range airfield southeast of Tonopah. Nevada. The unit and airplanes have been entered service since October of 1983.

洛克希德F-117A夜鹰

洛克希德F-117A夜鹰是一个长期极其秘密发展计划的成果,可远溯至70年代初期。为了测验能否设计出一种避开于雷达观测之外的飞机,曾进行无数计划和试验,洛克希德U-2漆有吸收雷达波的油漆。洛克希德SR-71同时有反雷达外形及吸收雷达波的油漆。量产型F-117A 1982年10月15日初次飞行,地点是位置偏远的内华达洲,高林湖飞行试验飞行基地。

此飞机是一种可于完全黑暗中隐闭行动的特殊任务战斗轰炸机。F-117A可以飞往世界各地,并有空中加油装置,巡航高度一般接近7600m。

F-117A夜鷹由美国空军战术飞行指挥部等37战术飞行纵队的飞行员驾驶。基地在内华达洲吞奴柏东南的吞奴柏实验飞行机场。这个单位及飞行自1983年1月开始已投入服役。



Cement parts 用酸粧接

> ballast (not included) 压仓物 (本品不包括)



DO Not cement

不用胶粘接

Please get the useful tools ready.Remove parts from frame with a pair of scissors and trim away excess plastic.Do not pull off parts Use cement sparingly to avoid damaging the model. please tear the plastic bag of this product to avoid children putting their heads into the bag. Do not put the parts into your mouth



Cut away 創去



使用工具应小心、注意安全。用模型剪从注塑片中取

出零件。修去多余料头及飞边。勿拔取零件。使用模型胶 勿过量。不得近火源。商品的空袋为了不让小孩套在头上

请撕掉。禁止把零部件含入口中

Caution

特别注意

Optional parts

可选的部分

Repeat op


更复操作






stick on the decal 贴上水贴纸


A tweeze










3









淡黑色 🛕

Noir Mat

1749 Model Maste 1730 Model Master FS37038 Flat Back Schwarz (M) Nero (0)

浅灰色 🚯

FS36440 Flat Gull Gray Mowengrau (M) Groggy Gabbiano (0) Gris Mouette Mat (M) 紅色 (C)

Rouge (B)

1503 Model Master 1524 Model Master 1745 Model Master Red Rot (G) Rosso (L)

绿色 D

Green Signal Verde (L) Vert (B)

白色 📵

FS17875 Insignia white Signalgrun (G) Bianco Segnaie (L) Verde Oliva (O) Bianc Insignes (B) Olive Sale (M)


橄榄绿 📵

1711 Model Master FS34087 Olive Drab Olive (M)

铬黄色 🕝

1790 Model Master FS17178 Chrome Silber Chromsilber (G) Argnto Cromo (1) Argent de Chrome(B) 浅黄色 🕕

1569 Model Master Flat yellow Gelb (M) Giallo (0) Jaune Mat (M)



Paniting instruction 涂 装 指 导 APPLYING DECALS 1. Gut off decal from sheel. 2. Dip the decal in tepid water for about 10 sec and place on a clean cloth. 3. Hold the backing sheet edge and slide decal onto the model. 4. Move decal into position by wetting decal with finger. 5. Press decal gently down with a soft cloth until excess water and air bubbles are gone. gone. 90亿印花水弘統)應用 1.由印花紙剪下印花。 2.海印花秋入温水中纳10秒然后放于干净布上。 3.崇印花移入模型上 4.手指沾水特放印花到位 5.用軟布輕輕壓即花直到水泡消失。



DF 312 ZHENGDEFU

12